

**DART****RELEASED**  
*10/18/02*

PPP

<b>Part Number</b>	D350-589-041	<b>Box Part Number</b>	MBX103	<b>Dimension</b>	L x W x H 60.5 x 8.5 x 33.5
<b>Description</b>	Side Door Assembly	<b>Other Packaging</b>	MF1612		
		<b>Logo Decals</b>	D3721-1		

**Packaging Instructions and Decal Placement****D350-589-041**

Place bubble wrap in bottom of box. Put the first side door in box and layer it with more bubble wrap. Tape one piece of MF1612 foam over the hinges on top of the bubble wrap to prevent rubbing or scratching on second door. Add in the second door and surround entire box with more bubble wrap to prevent movement. Place hardware and paperwork in the box. Staple down the lid and secure it with tie rap, tape and Dart tape. Apply label D2729-3 as per instructions in QSI 014 section 4.5 Secure it with tape and staples.

D2729-1

D2729-3

<b>DART</b> Dart Aerospace Ltd. 1270 ABERDEEN ST. HAWKESBURY, ON CANADA K6A 1K7		TC APPROVAL # 09-89 TEL: 1-613-632-5200	
<b>P/N</b>	D350-589-041	<b>CHG</b>	CHG006
<b>DESC</b>	Side Door Assembly, LH	<b>STC</b>	SH92-41
<b>LOT</b>	BXXXXX	<b>STC</b>	SH1012NE
<b>MODEL</b>	AS350	<b>STC</b>	
MADE IN CANADA			

<b>DART</b>	<b>Dart Aerospace Ltd.</b> 1270 Aberdeen Street Hawkesbury, ON K6A 1K7 CANADA TEL.: 1 613 632-5200
<b>SIDE DOOR ASSEMBLY, LH</b>	
<b>P//N: D350-589-041    CHG006</b>	
<b>B/N: BXXXXX</b>	

*10/10/13*  
*10.10.13* G Revision: *DE R 02.11.02*  
Date: *08.06.26 09.02.10*  
H:\Admin-qaliso\forms\PPP-1.Rev.A